

## **Coaxial Adaptors**

## BNC FEMALE TO .....

DING FEMALE TO			
UHF Male	BNC Female to UHF Male (NOVA)	CON-503	
SMA Female	BNC Female to SMA Female (Kenwood/GP900)	CON-507	
N Male	BNC Female to N Male (NOVA)	CON-512	
TNC Male	BNC Female to TNC Male (IRC/Chieftek/Kenwood)	CON-513	
BNC Female	BNC Female to BNC Female (NOVA)	CON-515	
Mini UHF	BNC Female to Mini UHF Male (NOVA)	CON-519	
SMA	BNC Female to SMA Male (Tait Orca/Yaesu/VX400)	CON-542	

Specification subject to change without notice. Issue 1



Tel: +27 11 719 0000 +27 21 702 1580
Fax: +27 11 444-2288 +27 21 702 1585
Web site: www.webb.co.za www.rcw.co.za clint@rcw.co.za

