

## SWR Analyser – MFJ269

Nova Code: **TES-400A**

Dual Meter

Can be used to adjust, test or measure

- Antennas
- Bandwidth
- Antenna Tuners
- Amplifiers
- Coaxial Transmission Lines
- Filter
- Matching or Tuning Stubs
- Traps
- Tuned Circuits Small
- Capacitors
- RF chokes & Inductors
- Transmitter & Oscillators



Specifications	TES-400A
Frequency	1.8 to 525 mHz
Pure Harmonic	-25 dBc @ 20 Milliwatt
Load	50Ω
Internal Impedance	50Ω

Measures & displays the following
○ Electrical length (Feet or Degrees)
○ Impedance phase angle (Degrees)
○ Resonance (mHz)
○ Feedline Loss (dB)
○ Inductance (H)
○ Return Loss (dB)
○ Capacitance (pF)
○ Reactance or X (Ohms)
○ Signal Frequency (mHz)
○ Impedance or Z magnitude (Ohms)
○ Resistance or R (Ohms)SWR (Zo Programmable)

Specification subject to change without notice. Issue 1